


Connecting your MiniSwitch

To connect MiniSwitch to your pedal use the included 1/4 inch TRS (stereo) cable.




Configuring the Pedal

To configure your Strymon pedal to work with MiniSwitch see your pedal's user manual or visit strymon.net/support


Selecting between TAP and FAV / BOOST MODE

Remove the four screws on the bottom of the chassis and locate the jumper underneath the circuit board. To select between the two modes, connect the jumper as shown below.

FAV / BOOST MODE



TAP MODE



MiniSwitch ships from the factory in FAV / BOOST mode.

Download the Complete manual: strymon.net/support

strymon